



Flatbed and Tipper Cargo Cover



by x8rltd

The Fault

Unsecure items in tippers and flatbeds are likely to be spilt, lost or stolen

Open back tippers, trailers and flat beds can have items easily stolen or spilt/lost in transportation if not properly secured.

The Solution

Fit our reinforced Nylon flatbed netting

Fit our X8R cargo cover to safely secure your fully loaded trailer. The netting is made from reinforced Nylon with webbed edging fortified with double stitching. These covers are particularly suitable for preventing sand, gravel and similar small particles from being blown away.

The covers are made from UV-resistant, air-permeable fabric which prevents the covers from bellying out in strong wind, or when containers are being moved.

It also comes with ultra-strong bungee cords to firmly attach it to your vehicle, looped through brass eyelets which won't rust.

Our cargo cover comes in a handy carry bag for easy and compact storage.

The measurements are 11ftx8ft complete with 6mm bungee cord. 0.5m distance between each brass eyelet.

Vehicles Affected

Universal item

This kit will fit many vehicles, it is impossible for us to list for all vehicles that our item will fit or to test on all vehicles / variants. Suitable for lorries, tippers, trailers, farm vehicles etc.

Ideal vehicles for this product are as follows:

- Iveco Daily
- Ford Transit Tipper
- Peugeot Boxer
- Citroen Relay
- Fiat Ducato

You Will Receive

1 x universal flatbed net complete with bungee cord & handy carry bag

Supplies:

No tools are needed to install this item.



Step 1: Locate Anchor Points

Locate the anchor points on your tipper. This Ford Transit Tipper comes with hooks underneath for an easy fit.





Step 2: Begin Attaching Cover

Start from the rear of the tipper. Attach the cover to the rear hooks.



Step 3: Drape Over Flatbed

Drape the cover over the rest of the tipper.



Step 4: Installation Is Complete

Anchor the bungee cord on all the hooks under the tipper. Once the net is secure it should have some resistance to it.

This completes the installation. If you need any further guidance on this install or would like to purchase the parts shown please call us on +44 01843 446643 or email us at sales@x8r.co.uk.

Please also check out our instruction guide on YouTube.

www.x8r.co.uk Installation is carried out at installers risk, if unsure please contact us or a professional, X8R Ltd cannot be held responsible for any adverse result of installing this product or any injuries caused by install, if in doubt ask a professional. All images and texts are copyright X8R Ltd 2023.



