



Pedal Guard Instruction Guide



by x8rltd

The Fault

It is common to have your van broken into and stolen.

Unfortunately it is becoming common for commercial vehicles to be broken into and stolen. Criminals can break into your vehicle by physically damaging the doors and bypassing the OEM locks, or replicating the OBD key coding to access keyless entry vehicles. If your vehicle shows no deterrent or additional security systems, they will become easy targets for thieves.

The Solution

Fit the X8R pedal guard system to prevent a break-in on your van.

The X8R pedal guard is made from 8mm thick anodised stainless steel. The design comprises of a base which clamps around the bottom of the pedals, then secured with a top bracket and a shackleless lock. The lock cannot be penetrated by bolt cutters like a traditional padlock. When not in use, the pedal guard can easily be stored in a glovebox or storage compartment, unlike other more bulky pedal guards on the market.

You will also receive a set of reflective, high visibility stickers to act as a deterrent. The two triangular stickers can be affixed to the windows or side of the vehicle, and the long sticker is for the pedal guard. The stickers reflect at night, so any thieves prospecting for vehicles to break into will be made aware of the pedal guard fitted to your van.

Vehicles Affected

We offer a multitude of different pedal guards, here are the part numbers and their compatibility:

X8R0265:

Mercedes Sprinter 2006-2018

Volkswagen Crafter 2006-2017

X8R0266:

Fiat Ducato 2015-2022

Peugeot Boxer 2015-2022

Citroen Relay 2015-2022

Automatic gearboxes only

X8R0267:

Fiat Ducato 2015-2022

Peugeot Boxer 2015-2022

Citroen Relay 2015-2022

Manual gearboxes only

X8R0268:

Fiat Ducato 2007-2014

Peugeot Boxer 2007-2014

Citroen Relay 2007-2014

Manual gearboxes only

X8R0269:

Ford Transit MK8 2014-2020

Not suitable for post 2020 facelift models

X8R0270:

Ford Transit MK7 2001-2014

You Will Receive:

x 1 Stainless steel anodised pedal guard with hi-vis sticker

x 1 Heavy duty shackleless van padlock with two keys

x 2 Hi-vis security window stickers

Supplies:

There are no tools needed to fit this kit



Step 1: Fit Pedal Guard

Remove the top from the base of the pedal guard and hook under the pedals. Place the shackleless lock over the top and lock into place.





Step 2: Fit Exterior Stickers

Fit the two exterior stickers. They can be fitted anywhere you like, but we highly recommend sticking them in the corner of your windows. All stickers provided in the kit (the 2 x exterior and 1 x pedal guard stickers) are highly reflective so will warn off potential thieves.

This completes the installation. If you need any further guidance on this install or would like to purchase the parts shown please call us on +44 01843 446643 or email us at sales@x8r.co.uk. Please also check out our instruction guide on YouTube. www.x8r.co.uk Installation is carried out at installers risk, if unsure please contact us or a professional, X8R Ltd cannot be held responsible for any adverse result of installing this product or any injuries caused by install, if in doubt ask a professional. All images and texts are copyright X8R Ltd 2023.

